

Sundance & Sweetwater Spas

Installation Instructions - Updated as of 08/30/12

## Step #1

Position the spa cover (in closed position) on the spa, making sure that all four corners are properly positioned and square on the spa.

Using the #10 x 1-1/2" screws, attach the Left and Right Mounting Brackets to the appropriate sides of the spa. Caution: to prevent splitting of wood cabinet, pre-drill holes with a 1/16" drill bit.

### Step #3

Connect the Pivot Arms to the Mounting Brackets (See Fig. 2). After the Pivot Arms are connected, tilt them back into the upright position.

### Step #4

Insert the long end of the Support Arms into the Center Coupler piece. Then slide the Support Arms into the Pivot Arms (See Fig. 3).

#### Step #5

Lay the Covermate on the spa cover. Adjust the Center Coupler piece and Support Arms so that the Center Coupler is lying parallel to the spa cover's hinge about 1/2" away (See Fig. 4). Using the #10 self tapping screws, fasten the Support Arms to the Pivot Arms and the Center Coupler piece. Note: Be sure to rotate the Center Coupler so that the inserted screws are at a horizontal angle with the heads facing the back of the spa.

#### Step #6

Slip the black hand grips to the edge of the spa cover and snap the Small Black Dome Caps on the heads of all exposed #10 screw heads.

#### Step #7

Attach the provided 3 hook TowelMate on the preferred side of your Covermate by simply snapping it into place and inserting the middle self tapping screw (See Fig. 5).

# **CAUTION!**

Do not use the Covermate in high wind condition. Injury from the spa cover being blown over and impacting the spa user can occur.



