





Step #1Mount your CMIII Shim in-between the Spa Skirting and the CMIII Bracket using the supplied #12 x 2-1/2" screws.

ITEM	PART#	DESCRIPTION	QTY
Α	101084	CMIII BRACKET SHIM	2
В	100600	#12 X 2-1/2" PHILIPS PAN HEAD SCREW	24