



Step #1:

Install the left and right ModStep drawer rails 3.25" in from the inside of the ModStep risers using the #8 x 1-1/4" self-tapping screws. *Note: Make sure the hole in the drawer rails closest to the end of the rail is facing toward the front of the step. The drawer rail must be screwed to the ModStep aluminum trim piece to properly secure the rail.*

Step #2:

Slide the drawer (flat side facing out) in between the ModStep drawer rails to make sure it slides in and out freely. *Note: If the drawer is too loose or too tight, adjust the position of the drawer rails to accommodate.*

Step #3:

Peel the backing off one of the foam oval drawer stops and stick it to the black side of another to make it double thick. Repeat for the other 2 foam oval drawer stops.

Step #4:

Slide the drawer half way out. Peel the backing off one of the double thick foam ovals and attach it to the underside of the tread toward the front left edge of drawer rails. Attach the second double thick foam oval near the front right edge of the drawer rail. *Note: These will eliminate the drawer from pulling all the way out.*

ITEM	PART#	DESCRIPTION	QTY
A	101635	MODSTEP DRAWER RAIL - LEFT	1
B	101636	MODSTEP DRAWER RAIL - RIGHT	1
C	101650	#8 X 1-1/4" PHILIPS FLAT HEAD SELF-TAPPING SCREW - BLACK	4
D	101649	MODSTEP FOAM OVAL DRAWER STOP	4
E	SMST-DRAWER	DRAWER	1