

**Step 1:** Slide the ModStep solar light panel throught the slot in the ModStep riser from the inside.

**Step 2:** Attach the foam spacer to the underside of the solar light panel up against the outside of the ModStep riser.





