



Step #1

Position the spa cover (in the closed position) on the spa, making sure that all four corners are properly positioned and square on the spa.

Step #2

Attach the mounting brackets 9" from the back of the spa acrylic using the #10 x 1" mounting screws. **Note: To prevent splitting of wood cabinet, pre-drill holes with a 1/16" drill bit.**

Step #3

Connect the pivot arms to the mounting brackets (see Fig. 2). After the pivot arms are connected, tilt them back into the upright position.

Step #4

Insert the long end of the support arms into the center coupler piece. Next, slide the support arms into the pivot arms (see Fig. 3).

Step #5

Lay the Covermate on the spa cover. Adjust the center coupler piece and support arms so the center coupler is laying parallel to the spa cover's hinge, about 1/2" away (see Fig. 4). Using the #10 self-drilling screws, fasten the support arms to the pivot arms and the center coupler piece. **Note: Be sure to rotate the center coupler so that the inserted screws are at a horizontal angle with the heads facing the back of the spa.**

Step #6

Slip the black hand grips to the edge of the spa cover and snap the small black dome caps on the heads of all exposed #10 screw heads. Push the 7/16" plug into the unused bracket (H) hole.

Step #7

Attach the provided 3 hook TowelMate on the preferred side of your Covermate by simply snapping it into place and inserting the middle self-drilling screw (see Fig. 5).

CAUTION!

Do not use the Covermate in high wind condition. Injury from the spa cover being blown over and impacting the spa user can occur.

Item	Part number	Description	Quantity
A	100001	SUPPORT ARM	2
B	100002	FOAM GRIP	2
C	100003	CENTER COUPLER	1
D	100004	PIVOT ARM	2
E	100007	PIVOT ARM CAP	2
F	100344	BUSHING	4
H	100503	MOUNTING BRACKET	2
I	100504	TOWELMATE	1
K	100568	3/8 X 3" HEX CAP BOLT	2
L	100596	3/8 NYLON LOCKNUT	2
M	100569	3/8 FLAT WASHER	4
N	100597	#10 X 5/8" SELF-DRILLING SCREWS	12
O	100008	#10 X 1" MOUNTING SCREWS	24
P	100026	LARGE BLACK DOME CAPS	2
Q	100011	SMALL BLACK DOME CAPS	36
R	100012	7/16" PLUG	2