

Step #1

Start by laying one of the risers on a flat surface. Insert the tread into the slots on the riser and loosely secure with the supplied #1/4 x 3/4" flat head machine screws, washers and locknuts (See Fig. 1).

Step #2

Insert the "U" shaped support channels into the same slot in the riser. **Note: Make sure the foam on each end of the support channel faces the tread.** Secure the "U" shaped support channels to the riser using the supplied #10 x 3/4" self-drilling screws (see Fig. 2).

Step #3



Attach the other riser onto the tread and support channels. Refer to step #1 and step #2 to loosely secure (see Fig. 3).

Step #4

Attach the rear brace to the back of the step and secure using the supplied 1/4 x 3/4" flat head screws, washers and locknuts (see Fig. 4).

Step #5

Go back through and make sure sure to tighten all of the flat head machine screws from step #1 & step #3.



ITEM	PART#	DESCRIPTION	QTY
A	102362	MOD STEP 3 RISER - LEFT	1
B	102363	MOD STEP 3 RISER - RIGHT	1
C	102351	MOD STEP REAR CROSS BRACE	1
D	102350	MOD STEP DOUBLE TREAD	1
E	102368	MOD STEP U SUPPORT CHANNEL	3
F	101396	1/4 x 3/4" FLAT HEAD MACHINE SCREW - SS	8
G	100608	1/4 FLAT WASHER	8
H	100607	1/4 NYLON LOCKNUT	8
I	101414	#10 X 3/4" PHILIPS PANCAKE HEAD SELF-TAPPING SCREW - SS	6

